Nashville Airport Database Migration Plan

Contents

Purpose	З
Camera Migration	2
Database Migration	
Jpdate Data Connection String	1(

Purpose

The purpose of this document is to outline and prescribe the steps required to merge the existing two VMS databases together and migrate the VMS database from the current Microsoft SQL Server 2008R2 server to the new Microsoft SQL Server 2017 server. This document will cover the migration of the existing database to the new server, as well as, the editing of each IP Server instance to reflect the new database location.

Camera Migration

Currently one camera resides on the new server (Enter Server Name). This camera will be migrated into the existing InsightEnt database.


- 1. Open a Windows Explorer window
- 2. Navigate to the saved location for the CameraMigration.sql file
- 3. Open Microsoft SQL Server Management Studio
- 4. Log into the SQL Server 2008R2 instance
- 5. Create the linked server to SQL Server 2017 instance
- 6. Click the "New Query" button (will open a blank query tab)
- 7. Drag and drop the CameraMigration.sql file from Windows Explorer to the SQL Management Studio blank query (will populate the contents of the .sql file into a new tab)
- 8. Edit CameraMigration.sql file to reflect linked server name (Find and Replace All)
- 9. Execute CameraMirgation.sql

Database Migration

- 10. On the Microsoft SQL Server 2017 server, open Microsoft SQL Server Management Studio
- 11. Log into the SQL Server 2017 instance
- 12. Click the "New Query" button (will open a blank query tab)
- 13. Enter the following query to create an empty InsightEnt database


CREATE DATABASE InsightEnt;

- 14. Click the "Execute" button or press F5 to execute the query
 - Successful response will be "Commands completed successfully."
- 15. In the left tree, click the minus sign (-) to the left of Databases to collapse the database folder
- 16. Click the blue circle arrow button of in Object Explorer toolbar to refresh database listing
- 17. In the left tree, click the plus sign (+) to the left of Databases to expand the database folder
- 18. Right-click on the InsightEnt database
- 19. Mouse over Tasks
- 20. Click "Import Data..." (will open SQL Server Import and Export Wizard"




21. If welcome screen appears, click next

- 22. In the "Choose a Data Source" window set the following values:
 - Data Source: SQL Server Native Client 11.0
 - Server Name: Server Name / IP Address and Instance name of old SQL Server
 - i. USE SQL Server Authentication; Enter Username and Password
 - Database: InsightEnt




23. Click Next

- 24. In the "Choose a Destination" window set the following values:
 - Data Source: SQL Server Native Client 11.0
 - Server Name: Should be prepopulated, if not enter gaining SQL Server Instance
 - i. USE SQL Server Authentication; Enter Username and Password
 - Database: InsightEnt (should be prepopulated)




- 25. Click Next
- 26. In the "Specify Table Copy or Query" window, click the radio button next to "Copy data from one or more tables or views"
- 27. Click Next

- 28. In the "Select Source Tables and Views" window:
 - Click the empty checkbox in the header bar to select all tables



- 29. Click Next
- 30. Click Finish in the "Save and Run Package" window
- 31. Click Finish in the "Complete the Wizard" window

32. The "Performing Operation" window will appear and display the progress of each table and the number of rows copied per table



- 33. Once complete the Close button becomes active, click Close to close the window
- 34. Expand the InsightEnt database in the Object Explorer to verify that tables have been imported

Update Data Connection String

After the database has been moved to the new server, the Data Connection Strings on each of the VI servers will need to be changed to reflect the new database location.

- 1. Open the Registry Editor
- 2. Navigate to HKEY_LOCAL_MACHINE\SOFTWARE\WOW6432Node\Video Insight\IP Server Ent
- 3. Double click on the DataConnectionString entry
- 4. Delete the existing value
- 5. Enter the new value
- 6. Click OK to accept the new value
- 7. Close the Registry Editor
- 8. Open IP Server Manager
- 9. Right-click on the IP Server Manager icon in the system tray
- 10. Click Start IP Server
- 11. IP Server icon will turn green